





# BRISTAN

TAPS & SHOWERS


## Installation Instructions & User Guide

Please leave these instructions with the end user

Product Code: FLT KIT C (D1)

Specifications	Inlet Water Temperature		Inlet Connections
<b>Dynamic Water Pressure (bar)</b>  Min: 0.2      Max: 5.0 Maximum Static Pressure: 10.0	<b>Cold Water Supply</b>  Min: 5°C Max: 20°C	<b>Hot Water Supply</b>  Min: 52°C Max: 65°C	 1/2" BSP

### Tools You'll Need



### Prior to Installation

All products manufactured and supplied by Bristan are safe provided they are installed, used correctly and receive regular maintenance in accordance with these instructions

Isolation valves **must** be fitted to the inlet water supplies to ensure ease of future maintenance.

This valve allows safe flushing of the tap or shower to avoid installation debris to clog up the mechanical areas of the valve.

This product **must** not be modified in any way as this will invalidate the guarantee.


Full access must be made available for future maintenance / servicing purposes.

This product needs to be installed in accordance with, and meet the requirements of the Water Supply (Water Fittings) Regulations 1999 and Scottish Byelaws 2004.

If in doubt, contact a registered plumber or your Local Water Authority or the Secretary of the Institute of Plumbing, address as follows:-

The Institute of Plumbing,  
64 Station Lane,  
Hornchurch,  
Essex,  
RM12 6NB, Tel: 01708 472791

### Pack Contents



### Why not visit our Youtube channel

To see our latest how-to videos, simply scan the QR code with your smart phone or tablet.



Alternatively visit [www.youtube.com/bristanTV](http://www.youtube.com/bristanTV)

### Installation


#### IMPORTANT:

When working near a basin, bath or shower insert plug or cover waste to prevent losing small parts.

Take care not to drop tools/equipment into basin, bath or shower during installation.




#### 1




Position the fixing bracket against the wall, ensuring it's straight. Mark the fixing positions and remove from the wall.

#### 2




Connect the water supply to the diverter inlet and secure to the wall. Screw the riser rail into the top of the diverter.

#### 3




Remove the wall bracket fixing. Secure the wall bracket to the wall surface. The bracket is adjustable to suit different wall types.

#### 4




Screw the shower rose on to the arm, ensuring the washers are in place.

#### 5



Screw the hose on to the diverter outlet.

#### 6



Connect the hose to the handset and place in the slider.

IMPORTANT

Prior to drilling check there are no hidden electrical cables or water supply pipes